

INSTRUCTION BOOK

OIL-INJECTED ROTARY SCREW COMPRESSORS

G 18, G 22, G 15L



Atlas Copco

Oil-injected rotary screw compressors

G 18, G 22, G 15L

Instruction book

Original instructions

COPYRIGHT NOTICE

Any unauthorized use or copying of the contents or any part thereof is prohibited.

This applies in particular to trademarks, model denominations, part numbers and drawings.

This instruction book is valid for CE as well as non-CE labelled machines. It meets the requirements for instructions specified by the applicable European directives as identified in the Declaration of Conformity.

2021 - 06

No. 2920 7119 21

www.atlascopco.com



Table of contents

1	Safety precautions.....	5
1.1	SAFETY ICONS.....	5
1.2	GENERAL SAFETY PRECAUTIONS.....	5
1.3	SAFETY PRECAUTIONS DURING INSTALLATION.....	6
1.4	SAFETY PRECAUTIONS DURING OPERATION.....	7
1.5	SAFETY PRECAUTIONS DURING MAINTENANCE OR REPAIR.....	8
1.6	DISMANTLING AND DISPOSAL.....	10
2	General description.....	11
2.1	INTRODUCTION.....	11
2.2	AIR FLOW.....	14
2.3	OIL SYSTEM.....	16
2.4	COOLING SYSTEM.....	17
2.5	REGULATING SYSTEM.....	18
2.6	CONTROL PANEL	19
2.7	ELECTRICAL SYSTEM.....	20
2.8	PROTECTION OF THE COMPRESSOR.....	22
2.9	AIR DRYER.....	23
3	Controller.....	24
3.1	CONTROLLER.....	24
3.2	CONTROL PANEL.....	25
3.3	ICONS USED ON THE DISPLAY.....	26
3.4	MAIN SCREEN.....	27
3.5	MAIN FUNCTION.....	28
3.6	SHUTDOWN WARNING.....	30
3.7	SHUTDOWN.....	31
3.8	SERVICE WARNING.....	34




3.9	SCROLLING THROUGH ALL SCREENS.....	36
3.10	CALLING UP RUNNING HOURS.....	37
3.11	CALLING UP MOTOR STARTS.....	38
3.12	CALLING UP MODULE HOURS.....	38
3.13	CALLING UP LOADING HOURS.....	39
3.14	CALLING UP LOAD SOLENOID VALVE.....	39
3.15	CALLING UP/RESETTING THE SERVICE TIMER.....	40
3.16	CALLING UP/MODIFYING PRESSURE BAND SELECTION.....	40
3.17	CALLING UP/MODIFYING PRESSURE BAND SETTINGS.....	41
3.18	CALLING UP/MODIFYING THE UNIT OF TEMPERATURE.....	41
3.19	CALLING UP/MODIFYING THE UNIT OF PRESSURE.....	41
3.20	CALLING UP/MODIFYING BACKLIGHT TIME.....	42
3.21	ACTIVATING AUTOMATIC RESTART AFTER VOLTAGE FAILURE.....	42
3.22	KEYBOARD LOCK.....	43
4	Installation.....	44
4.1	INSTALLATION PROPOSAL.....	44
4.2	DIMENSION DRAWINGS.....	46
4.3	ELECTRICAL CONNECTIONS	47
4.4	PICTOGRAPHS.....	50
5	Operating instructions.....	51
5.1	INITIAL START-UP.....	51
5.2	STARTING.....	53
5.3	STOPPING.....	55
5.4	TAKING OUT OF OPERATION.....	56
6	Maintenance.....	58
6.1	PREVENTIVE MAINTENANCE SCHEDULE.....	58
6.2	DRIVE MOTOR	59

6.3	OIL SPECIFICATIONS.....	60
6.4	OIL, FILTER AND SEPARATOR CHANGE	62
6.5	PDX/DDX FILTER CHANGE (OPTION).....	64
6.6	STORAGE AFTER INSTALLATION.....	65
6.7	SERVICE KITS.....	65
7	Adjustments and servicing procedures.....	66
7.1	AIR FILTER.....	66
7.2	COOLERS.....	67
7.3	SAFETY VALVE	67
7.4	BELT SET EXCHANGE AND TENSIONING	68
7.5	DRYER MAINTENANCE INSTRUCTIONS.....	71
8	Problem solving.....	73
9	Technical data.....	76
9.1	ELECTRIC CABLE SIZE.....	76
9.2	SETTINGS FOR OVERLOAD RELAY AND FUSES.....	78
9.3	REFERENCE CONDITIONS AND LIMITATIONS.....	80
9.4	COMPRESSOR DATA.....	80
10	Instructions for use.....	82
11	Guidelines for inspection.....	83

1 Safety precautions


1.1 Safety icons

Explanation

	Danger to life
	Warning
	Important note

1.2 General safety precautions

1. The operator must employ safe working practices and observe all related work safety requirements and regulations.
2. If any of the following statements does not comply with the applicable legislation, the stricter of the two shall apply.
3. Installation, operation, maintenance and repair work must only be performed by authorized, trained, specialized personnel. The personnel should apply safe working practices by use of personal protection equipment, appropriate tools and defined procedures.
4. The compressor is not considered capable of producing air of breathing quality. For air of breathing quality, the compressed air must be adequately purified according to the applicable legislation and standards.
5. Before any maintenance, repair work, adjustment or any other non-routine checks:
 - Stop the machine
 - Press the emergency stop button
 - Switch off the voltage
 - Depressurize the machine
 - Lock Out - Tag Out (LOTO):
 - Open the power isolating switch and lock it with a personal lock
 - Tag the power isolating switch with the name of the service technician.
 - On units powered by a frequency converter, wait 10 minutes before starting any electrical repair.
 - Never rely on indicator lamps or electrical door locks before maintenance work, always disconnect and check with measuring device.

	If the machine is equipped with an automatic restart after voltage failure function and if this function is active, be aware that the machine will restart automatically when the power is restored if it was running when the power was interrupted!
-------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

6. Never play with compressed air. Do not apply the air to your skin or direct an air stream at people. Never use the air to clean dirt from your clothes. When using the air to clean equipment, do so with extreme caution and wear eye protection.
7. The owner is responsible for maintaining the unit in safe operating condition. Parts and accessories shall be replaced if unsuitable for safe operation.
8. It is prohibited to walk or stand on the unit or on its components.

9. If compressed air is used in the food industry and more specifically for direct food contact, it is recommended, for optimal safety, to use certified Class 0 compressors in combination with appropriate filtration depending on the application. Please contact your customer center for advice on specific filtration.
10. The service switch should only be operated by a trained service specialist from the manufacturer.

1.3 Safety precautions during installation



All responsibility for any damage or injury resulting from neglecting these precautions, or non-observance of the normal caution and care required for installation, operation, maintenance and repair, even if not expressly stated, will be disclaimed by the manufacturer.

Precautions during installation

1. The machine must only be lifted using suitable equipment in accordance with the applicable safety regulations. Loose or pivoting parts must be securely fastened before lifting. It is strictly forbidden to dwell or stay in the risk zone under a lifted load. Lifting acceleration and deceleration must be kept within safe limits. Wear a safety helmet when working in the area of overhead or lifting equipment.
2. The unit is designed for indoor use. If the unit is installed outdoors, special precautions must be taken. Consult your supplier.
3. In case the device is a compressor, place the machine where the ambient air is as cool and clean as possible. If necessary, install a suction duct. Never obstruct the air inlet. Care must be taken to minimize the entry of moisture at the inlet air.
4. Any blanking flanges, plugs, caps and desiccant bags must be removed before connecting the pipes.
5. Air hoses must be of correct size and suitable for the working pressure. Never use frayed, damaged or worn hoses. Distribution pipes and connections must be of the correct size and suitable for the working pressure.
6. In case the device is a compressor, the aspirated air must be free of flammable fumes, vapors and particles, e.g. paint solvents, that can lead to internal fire or explosion.
7. In case the device is a compressor, arrange the air intake so that loose clothing worn by people cannot be drawn in.
8. Ensure that the discharge pipe from the compressor to the aftercooler or air net is free to expand under heat and that it is not in contact with or close to flammable materials.
9. No external force may be exerted on the air outlet valve; the connected pipe must be free of strain.
10. If remote control is installed, the machine must bear a clear sign stating: DANGER: This machine is remotely controlled and may start without warning.
The operator has to make sure that the machine is stopped and depressurized and that the electrical isolating switch is open, locked and labelled with a temporary warning before any maintenance or repair. As a further safeguard, persons switching on or off remotely controlled machines shall take adequate precautions to ensure that there is no one checking or working on the machine. To this end, a suitable notice shall be affixed to the start equipment.
11. Air-cooled machines must be installed in such a way that an adequate flow of cooling air is available and that the exhausted air does not recirculate to the compressor air inlet or cooling air inlet.

12. The electrical connections must correspond to the applicable codes. The machines must be earthed and protected against short circuits by fuses in all phases. A lockable power isolating switch must be installed near the compressor.
13. On machines with automatic start/stop system or if the automatic restart function after voltage failure is activated, a sign stating "This machine may start without warning" must be affixed near the instrument panel.
14. In multiple compressor systems, manual valves must be installed to isolate each compressor. Non-return valves (check valves) must not be relied upon for isolating pressure systems.
15. Never remove or tamper with the safety devices, guards or insulation fitted on the machine. Every pressure vessel or auxiliary installed outside the machine to contain air above atmospheric pressure must be protected by a pressure relieving device or devices as required.
16. Piping or other parts with a temperature in excess of 70°C (158°F) and which may be accidentally touched by personnel in normal operation must be guarded or insulated. Other high temperature piping must be clearly marked.
17. For water-cooled machines, the cooling water system installed outside the machine has to be protected by a safety device with set pressure according to the maximum cooling water inlet pressure.
18. If the ground is not level or can be subject to variable inclination, consult the manufacturer.
19. If the device is a dryer and no free extinguishing system is present in the air net close to the dryer, safety valves must be installed in the vessels of the dryer.



Also consult the following safety precautions: [Safety precautions during operation](#) and [Safety precautions during maintenance](#).
 These precautions apply to machinery processing or consuming air or inert gas. Processing of any other gas requires additional safety precautions typical to the application which are not included herein.
 Some precautions are general and cover several machine types and equipment; hence some statements may not apply to your machine.

1.4 Safety precautions during operation



All responsibility for any damage or injury resulting from neglecting these precautions, or non observance of the normal caution and care required for installation, operation, maintenance and repair, even if not expressly stated, will be disclaimed by the manufacturer.

Precautions during operation

1. Never touch any piping or components of the machine during operation.
2. Use only the correct type and size of hose end fittings and connections. When blowing through a hose or air line, ensure that the open end is held securely. A free end will whip and may cause injury. Make sure that a hose is fully depressurized before disconnecting it.
3. Persons switching on remotely controlled machines shall take adequate precautions to ensure that there is no one checking or working on the machine. To this end, a suitable notice shall be affixed to the remote start equipment.
4. Never operate the machine when there is a possibility of taking in flammable or toxic fumes, vapors or particles.
5. Never operate the machine below or in excess of its limit ratings.

6. Keep all bodywork doors shut during operation. The doors may be opened for short periods only, e.g. to carry out routine checks. Wear ear protectors when opening a door. On machines without bodywork, wear ear protection in the vicinity of the machine.
7. People staying in environments or rooms where the sound pressure level reaches or exceeds 80 dB(A) shall wear ear protectors.
8. Periodically check that:
 - All guards are in place and securely fastened
 - All hoses and/or pipes inside the machine are in good condition, secure and not rubbing
 - No leaks occur
 - All fasteners are tight
 - All electrical leads are secure and in good order
 - Safety valves and other pressure relief devices are not obstructed by dirt or paint
 - Air outlet valve and air net, i.e. pipes, couplings, manifolds, valves, hoses, etc. are in good repair, free of wear or abuse
 - Air cooling filters of the electrical cabinet are not clogged
9. If warm cooling air from compressors is used in air heating systems, e.g. to warm up a workroom, take precautions against air pollution and possible contamination of the breathing air.
10. On water-cooled compressors using open circuit cooling towers, protective measures must be taken to avoid the growth of harmful bacteria such as Legionella pneumophila bacteria.
11. Do not remove any of, or tamper with, the sound-damping material.
12. Never remove or tamper with the safety devices, guards or insulations fitted on the machine. Every pressure vessel or auxiliary installed outside the machine to contain air above atmospheric pressure shall be protected by a pressure relieving device or devices as required.
13. Yearly inspect the air receiver. Minimum wall thickness as specified in the instruction book must be respected. Local regulations remain applicable if they are more strict.



Also consult following safety precautions: [Safety precautions during installation](#) and [Safety precautions during maintenance](#).

These precautions apply to machinery processing or consuming air or inert gas. Processing of any other gas requires additional safety precautions typical to the application which are not included herein.

Some precautions are general and cover several machine types and equipment; hence some statements may not apply to your machine.

1.5 Safety precautions during maintenance or repair



All responsibility for any damage or injury resulting from neglecting these precautions, or non observance of the normal caution and care required for installation, operation, maintenance and repair, even if not expressly stated, will be disclaimed by the manufacturer.

Precautions during maintenance or repair

1. Always use the correct safety equipment (such as safety glasses, gloves, safety shoes, etc.).
2. Use only the correct tools for maintenance and repair work.

3. Use only genuine spare parts for maintenance or repair. The manufacturer will disclaim all damage or injuries caused by the use of non-genuine spare parts.
4. All maintenance work shall only be undertaken when the machine has cooled down.
5. A warning sign bearing a legend such as "Work in progress; do not start" shall be attached to the starting equipment.
6. Persons switching on remotely controlled machines shall take adequate precautions to ensure that there is no one checking or working on the machine. To this end, a suitable notice shall be affixed to the remote start equipment.
7. Close the compressor air outlet valve and depressurize the compressor before connecting or disconnecting a pipe.
8. Before removing any pressurized component, effectively isolate the machine from all sources of pressure and relieve the entire system of pressure.
9. Never use flammable solvents or carbon tetrachloride for cleaning parts. Take safety precautions against toxic vapors of cleaning liquids.
10. Scrupulously observe cleanliness during maintenance and repair. Keep dirt away by covering the parts and exposed openings with a clean cloth, paper or tape.
11. Never weld or perform any operation involving heat near the oil system. Oil tanks must be completely purged, e.g. by steam cleaning, before carrying out such operations. Never weld on, or in any way modify, pressure vessels.
12. Whenever there is an indication or any suspicion that an internal part of a machine is overheated, the machine shall be stopped but no inspection covers shall be opened before sufficient cooling time has elapsed; this to avoid the risk of spontaneous ignition of the oil vapor when air is admitted.
13. Never use a light source with open flame for inspecting the interior of a machine, pressure vessel, etc.
14. Make sure that no tools, loose parts or rags are left in or on the machine.
15. All regulating and safety devices shall be maintained with due care to ensure that they function properly. They may not be put out of action.
16. Before clearing the machine for use after maintenance or overhaul, check that operating pressures, temperatures and time settings are correct. Check that all control and shut-down devices are fitted and that they function correctly. If removed, check that the coupling guard of the compressor drive shaft has been reinstalled.
17. Every time the separator element is renewed, examine the discharge pipe and the inside of the oil separator vessel for carbon deposits; if excessive, the deposits should be removed.
18. Protect the motor, air filter, electrical and regulating components, etc. to prevent moisture from entering them, e.g. when steam cleaning.
19. Make sure that all sound-damping material and vibration dampers, e.g. damping material on the bodywork and in the air inlet and outlet systems of the compressor, is in good condition. If damaged, replace it by genuine material from the manufacturer to prevent the sound pressure level from increasing.
20. Never use caustic solvents which can damage materials of the air net, e.g. polycarbonate bowls.
21. **Only if applicable, the following safety precautions are stressed when handling refrigerant:**
 - Never inhale refrigerant vapors. Check that the working area is adequately ventilated; if required, use breathing protection.
 - Always wear special gloves. In case of refrigerant contact with the skin, rinse the skin with water. If liquid refrigerant contacts the skin through clothing, never tear off or remove the latter; flush abundantly with fresh water over the clothing until all refrigerant is flushed away; then seek medical first aid.



Also consult following safety precautions: [Safety precautions during installation](#) and [Safety precautions during operation](#).
These precautions apply to machinery processing or consuming air or inert gas. Processing of any other gas requires additional safety precautions typical to the application which are not included herein.
Some precautions are general and cover several machine types and equipment; hence some statements may not apply to your machine.

1.6 Dismantling and disposal

Dismantling

Once the end of life of the machine is reached, please follow next steps:

1. Stop the machine.
2. Check all safety precautions mentioned in the previous chapters to secure safe handling (e.g. LOTO, cool-down, depressurize, discharge, ...).
3. Separate the harmful from the safe components (e.g. drain oil from oil containing parts).
4. Refer to the disposal topic mentioned below.

Disposal of electrical and electronic appliances (WEEE)

This equipment falls under the provisions of the European Directive 2012/19/EU on waste electrical and electronic appliances (WEEE) and may not be disposed as unsorted waste.



The equipment is labelled in accordance with the European Directive 2012/19/EU with the crossed-out wheeled bin symbol.

At the end of life-time of the electric and electronic equipment (EEE) it must be taken to separate collection.

For more information check with your local waste authority, customer center or distributor.

Disposal of other used material

Used filters or any other used material (e.g. filter bags, filter media, desiccant, lubricants, cleaning rags, machine parts, etc.) must be disposed of in an environmentally friendly and safe manner, and in line with the local recommendations and environmental legislation.

2 General description

2.1 Introduction

Introduction

G 15L, G 18 and G 22 are air-cooled, single-stage, oil-injected screw compressors, driven by an electric motor.

The compressors are enclosed in sound-insulating bodywork.


An easy-to-operate control panel is provided, including the start/stop switch and the emergency stop button. A cabinet housing the controller, pressure sensor and motor starter is integrated into the bodywork.

Floor-mounted model

The compressor is installed directly on the floor.

Tank-mounted model


G 15L, G 18 and G 22 tank-mounted units are supplied with an air receiver of 500 l (132 US gal / 110 Imp gal / 17.5 cu.ft).



Front view, G 18 Full-Feature tank-mounted

Reference	Designation
1	Electric cabinet
ER	Elektronikon™ Base Controller
S3	Emergency stop button

Reference	Designation
AO	Air outlet
AR	Air receiver
Dm1	Manual condensate drain
DR	Dryer
D	Dewpoint indicator (only on Full-Feature units)
DMS	Dryer main switch (only on Full-Feature units)



Front open view, G 18 Full-Feature tank-mounted

Reference	Designation
Co	Oil cooler
OF	Oil filter
OS	Oil separator
OT	Oil separator tank




Rear open view, G 18 Full-Feature tank-mounted

Reference	Designation
Ca	Air cooler
E	Compressor element
AF	Air filter

2.2 Air flow


Pack



Air flow, G 15L, G 18 and G 22 Tank-mounted Pack

Air drawn through filter (AF) and open inlet valve (IV) into compressor element (E) is compressed. Compressed air and oil flow into oil separator/tank (OT). The air is discharged via minimum pressure valve (VP) and air cooler (Ca) towards the air outlet (AO).


Full-Feature




Air flow, G 15L, G 18 and G 22 Tank-mounted Full-Feature

Air drawn through filter (AF) and open inlet valve (IV) into compressor element (E) is compressed. Compressed air and oil flow into oil separator/tank (OT). The air is discharged via minimum pressure valve (Vp), air cooler (Ca) and air dryer (DR) towards the air outlet (AO).

2.3 Oil system



Oil system, G 15L, G 18 and G 22 Pack




Oil system, G 15L, G 18 and G 22 Full-Feature

Air pressure in the oil separator tank (OT) forces the oil from the tank to compressor element (E) via oil cooler (Co) and oil filter (OF). Compressed air and oil flow into oil separator/tank (OT) where most of the oil is separated from the air by centrifugal action. The remaining oil is removed by oil separator (OS) and returns to the oil circuit via a separate line. The minimum pressure

valve (Vp - see section [Air flow](#)) ensures a minimal pressure in the tank, required for oil circulation under all circumstances.


The oil system is fitted with a by-pass valve (BV). When the oil temperature is below the set-point of the valve, the by-pass valve shuts off the oil supply from oil cooler. The by-pass valve starts opening the supply from cooler (Co) when the oil temperature exceeds the setting of the valve. The setting of the by-pass valve depends on the model. See section [Compressor data](#).

2.4 Cooling system



Cooling system, G 15L, G 18 and G 22 Pack

The cooling system of the Pack version comprises oil cooler (Co) and fan (FN). The fan, mounted directly onto the motor shaft, generates the cooling air in order to cool the oil and the internal parts of the compressor.




84817D
Cooling system, G 15L, G 18 and G 22 Full-Feature

The cooling system of the Full-Feature version comprises oil cooler (Co), air cooler (Ca) and fan (FN).

The dryer (DR) of Full-Feature versions has a separate cooling fan and an automatic condensate drain (see also section [Air dryer](#)).

2.5 Regulating system



80740F
Detail view of unloader assembly (UA)

The main components of the regulating system are:

- Unloader (UA), including inlet valve (IV) and unloading valve (UV).

- Loading solenoid valve (Y1).
- The Base controller that regulates the compressor based on the pressure settings and readings of the pressure sensor.

Loading

If the working pressure is below the preset maximum, the solenoid valve (Y1) is energized and therefore closed. There is no signal air flow into unloader allowing the inlet valve to open due to the element suction.

The inlet valve opens completely allowing the air through the air filter (AF) and the compressor will run fully loaded (100% output).

The unit stops loading when the set 'Unload' pressure is reached, the machine will run unloaded.

Unloading

When the working pressure reaches the maximum limit, the solenoid valve is de-energized, venting the control air: the inlet valve closes completely and the unloading valve opens completely. The compressor will run unloaded (0% output).

The G 15L, G 18 and G 22 are equipped with an intelligent controller that will stop the compressor after a variable period of unloaded operation using the following control algorithm:


- At power on, in the first work cycle, the 'Unload' period is 30 seconds.
- After the first work cycle, and in all other working cycles, the 'Unload' period is calculated following 3 rules:
 - a. Given a maximum number of 10 restarts per hour (factory setting), the total running period per cycle ('Load' time + 'Unload' time) must be minimum 6 minutes (360s).
 - b. At the end of the unload period the controller checks the air consumption and decides whether to stop the unit or restart to anticipate the air demand.
 - c. Motor virtual temperature calculation.
If the unit is restarting frequently, or is manually restarted by the operator, the controller will extend the unload period in order to ensure proper motor cooling. This overrules the standard unload period.

The compressor will automatically restart when the net pressure drops to the minimum limit.

The compressor will automatically restart when the net pressure drops to the minimum limit.

2.6 Control panel

Control panel




Control panel G 15L, G18 and G 22

Reference	Designation
1	Electric cabinet
ER	Elektronikon™ Base controller
S3	Emergency stop button
DMS	Dryer Main Switch (Only on Full-Feature units)


2.7 Electrical system

Electrical components

The electrical system comprises the following components:



Electric cubicle IEC



Electric cubicle cULus / cCSAus

Reference	Designation
F1	Primary fuse, transformer of the control circuit
F2	Phase sequence relay fuse
F3-4-5-6	Fuses
F7	Primary fuse, transformer of the dryer
F8	Secondary fuse, transformer of the dryer
F21	Motor overload relay
K5	Auxiliary circuit relay
K23	Delta contactor
K21	Line contactor
K11	Dryer relay (only on Full-Feature)
K22	Star contactor
K25	Phase sequence relay
PC	Protection cover
T1	Control transformer
T2	Dryer transformer
1X0	Terminal block, power supply
X2	Terminal block of the control circuit
1X1	Terminal block, voltage change of the motor (only on tri-voltage units)
1XM	Terminal block, main motor


Electrical diagram

2205 0147 00	Service diagram G 15L – G 18 – G 22 IEC
2205 0324 00	Service diagram G 15L – G 18 – G 22 cULus/ cCSAus

The complete electrical diagram can be found in the electric cubicle.

The complete electrical diagram can be found on the USB supplied with the machine.


2.8 Protection of the compressor



Safety valve on the compressor and on the vessel

Reference	Designation	Function
SV	Safety valve	To protect the air outlet system if the outlet pressure exceeds the opening pressure of the valve.

2.9 Air dryer




Air Dryer

Wet compressed air enters the dryer and is further cooled by the outgoing, dried air (2). Moisture in the incoming air condenses. The air then flows through heat exchanger (1) where refrigerant evaporates, withdrawing heat from the air. The cold air then flows through condensate trap (4) which separates condensate from the air. The condensate is automatically drained. The cold, dried air then flows through heat exchanger (3), where it is warmed up by the incoming air.

3 Controller

3.1 Controller

Control panel



84891D

Introduction

In general, the controller has the following functions:

- Controlling the compressor;
- Protecting the compressor;
- Monitoring service intervals;
- Automatic restart after voltage failure (made inactive);

Automatic control of the compressor

The controller maintains the net pressure between programmable limits by automatically loading and unloading the compressor. A number of programmable settings are taken into account, e.g. the unloading and loading pressures, the minimum stop time and the maximum number of motor starts.

The controller stops the compressor whenever possible to reduce power consumption and restarts it automatically when net pressure decreases. If the expected unloading period is too short, the compressor is kept running to prevent too short standstill periods.

Protecting the compressor

Shutdown temperature warning

The shutdown temperature warning is a programmable warning that advises the operator that the shutdown temperature is nearly reached. If the measured temperature exceeds the programmed

shutdown warning temperature, this will be indicated on the controller display before the shutdown temperature is reached.

Shutdown

If the compressor element outlet temperature exceeds the programmed shutdown level or the overload relay of the main motor trips, the compressor will be stopped. This will be indicated on the display of the controller.


Service warning

If the service timer exceeds the preset value, the controller advises the operator via the display, to carry out the service maintenance.

Automatic restart after voltage failure

The controller has a built-in function to automatically restart the compressor when the voltage is restored after voltage failure. This function is deactivated on compressors leaving the factory.








3.2 Control panel








Reference	Designation	Function
1	Display	Shows icons and operating conditions.

Reference	Designation	Function
2	LED, Voltage on	Indicates that the voltage is switched on.
3	Start/stop button	Keep pressed for 3 seconds to start compressor. Press to stop compressor if running. Use this button to go to previous screen or to end the current action.
4	Scroll button	Use these buttons to scroll through the menu.
5	LED, Warning	Is lit if a warning condition exists.
6	LED, Service	Is lit when service is needed.
7	Enter button	Press 3 seconds to enter in menu. Use this button to confirm the last action. Press 5 seconds to reset alarm.
8	Scroll button	Use these buttons to scroll through the menu.

3.3 Icons used on the display


Function	Icon	Description
Stopped/Running		When the compressor is stopped, the icon stands still. When the compressor is running, the icon is rotating.
Compressor status		Motor stopped
		Running unloaded Running unloaded (blinking for manual stop)
		Running loaded
Machine control mode		Remote start/stop active
Automatic restart after voltage failure		Automatic restart after voltage failure is active
Active protection functions		Emergency stop

Function	Icon	Description
Service	 85013D	Service required
Units	MPa 85017D	Pressure unit (Mega Pascal)
	psi 85019D	Pressure unit (pounds per square inch)
	bar 85011D	Pressure unit (bar)
	°C 85018D	Temperature unit (degree Centigrade)
	°F 85001D	Temperature unit (degree Fahrenheit)
	 85015D	Motor
	 x1000 hrs 85016D	A time/delay parameter is displayed. NOTE: <ul style="list-style-type: none"> • x1000: ON if the displayed value is in thousands of • hrs: ON if the displayed value is in hours • s: ON if the displayed value is in seconds
	  85011D	Element outlet temperature

3.4 Main screen


At power on, the first screen is a test screen (Icon, digit and led are on). The next screen is the Main screen, shown automatically. The Main screen shows:

- The compressor status by means of pictographs;
- The air outlet pressure;



Main screen with pressure (stopped compressor)


From the Main screen it is possible with up and down buttons (4-8) to change the view from pressure to temperature of the element outlet.



Main screen with temperature (stopped compressor)


3.5 Main function

To switch on the compressor, press the start/stop button (3) for 3 seconds. The compressor starts and the status is shown:




Screen with running compressor

To stop the compressor, push the start/stop button (3). The compressor unloads:



Screen with unloading compressor

After the unload time has elapsed, the compressor is stopped and the controller goes back to main screen:



Main screen with pressure (stopped compressor)


To enter the main menu (starting from the Main screen), press the enter button (7) for 3 seconds. The main menu is shown:



First screen of main menu


It is possible to scroll in the menu with the up or down buttons (4-8). To select one item push the enter button (7). To end the current action push start/stop (3) button.

If the emergency stop button is pushed, the compressor stops immediately and the following screen will appear:



Emergency stop

When the emergency push button is restored, reset the alarm by pressing the enter button (7) for 5 seconds. The following screen will appear:



Alarm reset

3.6 Shutdown warning


Description

A shutdown warning will appear in the event of:

- A too high temperature at the outlet of the compressor element.

Compressor element outlet temperature

- If the outlet temperature of the compressor element exceeds the shutdown warning level (factory set at 110°C/ 230°F), warning LED (5) is on.
- Press Scroll up or down buttons (4-8). The screen shows the temperature at the compressor element outlet.



It remains possible to check the actual status of other parameters by pressing the enter button (7) for 3 seconds. Press button (3) to stop the compressor and wait until the compressor has stopped. The warning message will disappear as soon as the warning condition disappears.

3.7 Shutdown

Description


The compressor will stop:

- In case the temperature at the outlet of the compressor element exceeds the shutdown level, detected by the temperature sensor or by the temperature switch.
- In case of error of the outlet pressure sensor or temperature sensor.
- In case of overload of the compressor motor.
- In case of incorrect phase sequence, detected by the phase sequence relay.

Compressor element outlet temperature

If the outlet temperature of the compressor element exceeds the shutdown level (factory setting 115°C/239°F):

- The compressor will stop.
- Alarm LED (5) will flash.
- The following screen will appear:




Main screen with shutdown indication, element outlet temperature

- The related pictograph



will appear flashing.

- Scroll Up or Down buttons (4-8) until the current element outlet temperature appears.



Shutdown screen, element outlet temperature


The screen shows that the temperature at the outlet of the compressor element is 117 °C.

- When the shutdown condition has been solved, press the Enter button (7) for 5 seconds.
- When <rSt> appears on the display, the compressor can be restarted.

Error pressure/temperature sensor

In the event of an error of the outlet pressure sensor (PT20) or temperature sensor (TT11):

- The compressor will stop.
- The following screen will appear:




Example of error sensor

Motor overload

In the event of motor overload:

- The compressor will stop.
- Alarm LED (5) will flash.
- The following screen will appear:



Main screen with shutdown indication, motor overload

- Contact your supplier for fault troubleshooting
- When the shutdown condition has been solved, press the enter button (7) for 5 seconds.
- When <rSt> appears on the display, the compressor can be restarted.

Incorrect phase sequence

In the event of wrong phase sequence:

- The compressor will not start.
- Alarm LED (5) will flash.
- The following screen will appear:



Main screen with shutdown indication, phase sequence incorrect


- Switch off the voltage, open the disconnecter switch and reverse two phases of the supply cable.
- Switch on the voltage and restart the compressor. The shutdown message will disappear automatically when the shutdown condition has disappeared.

3.8 Service warning

Description

A service warning will appear when the service timer has reached the preset time interval.

If the service timer exceeds the programmed time interval, alarm LED (6) is blinking with a following screen:



Blinking screen

- Press Enter button (7) to enter the main menu.
- Select <dAtA> and press Enter button (7) to enter the data menu.
- Scroll (buttons 4-8) until <d.6> and the service symbol is shown.
- Press enter button (7).
- The actual reading of the service timer is shown in <hrs>.



Example of running hours screen

The example screen shows that the service timer is at 2002 hours.


Stop the compressor, switch off the voltage and carry out the required service actions.

After servicing, reset the service timer.

See section [Calling up/resetting the service timer](#).

3.9 Scrolling through all screens

Control panel



General overview of the menu structure

From the Main screen press the enter button (7) for 3 seconds to enter the Menu. You will find the following items:

dAtA	Data counters parameters.
ProG	Submenu of Regulation pressure, Timer, Display setting and Control setting.
tEst	Display test.
InFo	Information of firmware release.

Overview of the screens


Menu item	Submenu	Digital input screen	Designation
<dAtA> (Data)		<d.1>	Running hours.
		<d.2>	Motor starts.
		<d.3>	Module hours.
		<d.4>	Loading hours.
		<d.5>	Load solenoid valve.
		<d.6>	Service timer.
<ProG> (Programming)	<rEG.P> (Regulation Pressure)	<Pr.SL>	Calling up or modifying pressure band selection.
		<LPr.1>	Calling up or modifying lower pressure setting.
		<uPr.1>	Calling up or modifying upper pressure setting.
		<LPr.2>	Calling up or modifying lower pressure setting.
		<uPr.2>	Calling up or modifying upper pressure setting.
	<tiMr> (Timer) (password required)	<SrV.d>	Maintenance warning.
	<diSP> (Display)	<tEMP>	Calling up or modifying unit of temperature.
		<PrES>	Calling up or modifying unit of pressure.
		<bC.LG>	Calling up or modifying time of backlight.
	<Ctrl> (Control) (password required)	<Lo.rE>	Local/remote start/stop.
		<Ar.Af>	Automatic restart after voltage failure.
		<Ar.d>	Delay time of automatic restart after voltage failure.
		<nHCA>	Maximum number of compressor starts per hour.
	<PASS>		Activating password protection.
	<tESt> (Test)		<tSt.1>
<InFo> (Info)		<P.rEL>	Parameter map release.
		<F.rRI>	Firmware release.
		<F.dAY>	Firmware release day.
		<F.Mnt>	Firmware release month.
		<F.YAr>	Firmware release year.
		<SEr.n>	Serial number.

3.10 Calling up running hours

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.

- Select <dAtA> and press Enter button (7) to enter the Data menu.
- Scroll Up or Down buttons (4-8) until <d.1> and the motor stopped symbol is shown.
- Press Enter button (7): the running hours are shown.




The screen shows the unit used <x1000 hrs> and the value <11.25>: the running hours of the compressor are 11250 hours.

3.11 Calling up motor starts

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <dAtA> and press Enter button (7) to enter the Data menu.
- Scroll Up or Down buttons (4-8) until <d.2> and the motor symbol is shown.
- Press Enter button (7): the number of motor starts is shown.



This screen shows the number of motor starts (x1 or - if <x1000> lights up - x1000). In the above example, the number of motor starts is 10100.

3.12 Calling up module hours

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <dAtA> and press Enter button (7) to enter the Data menu.
- Scroll Up or Down buttons (4-8) until <d.3> and <hrs> is shown.
- Press Enter button (7): the module time appears.




In the example shown, the screen shows the unit used <hrs> and the value <5000>: the controller module has been in service during 5000 hours.

3.13 Calling up loading hours

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <dAtA> and press Enter button (7) to enter the Data menu.
- Scroll Up or Down buttons (4-8) until <d.4> and the running loaded symbol is shown.
- Press Enter button (7): the loading time is shown.




The screen shows the unit used <hrs> (or <x1000 hrs>) and the value <1755>: the compressor has been running loaded during 1755 hours.

3.14 Calling up load solenoid valve

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <dAtA> and press Enter button (7) to enter the Data menu.
- Scroll Up or Down buttons (4-8) until <d.5> and the running loaded symbol is shown.
- Press Enter button (7): the number of loadings is shown.



This screen shows the number of loading actions (x1 or - if <x1000> lights up - x1000). In the above example, the number of unload to load actions is 10100.

3.15 Calling up/resetting the service timer

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <dAtA> and press Enter button (7) to enter the Data menu.
- Scroll Up or Down buttons (4-8) until <d.6> and <hrs> is shown.
- Press Enter button (7): the service timer is shown.




This screen shows the unit used (<hrs> or <x1000 hrs>) and the value. In the example shown, the compressor has run 1191 hours since the previous service.

Reset can only be performed by authorized personnel. Contact your supplier for further details.

3.16 Calling up/modifying pressure band selection

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <ProG> and press Enter button (7) to enter the Programming menu.
- Scroll Up or Down buttons (4-8) to <reG.P> for regulation pressure.
- Press Enter button (7) to enter the submenu.



- Scroll Up or Down buttons (4-8) until <PrSL> is shown and then press Enter button (7).
- Pressure band 1 (<SEL.1>) is shown. Scroll Up or Down buttons (4-8) to pressure band 2 (<SEL.2>).
- Press Enter button (7) on the desired pressure band.

3.17 Calling up/modifying pressure band settings

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <ProG> and press Enter button (7) to enter the Programming menu.
- Scroll Up or Down buttons (4-8) to <reG.P> for regulation pressure.
- Press Enter button (7) to enter the submenu.

<LPr.1> is the parameter of Load Pressure band 1

<uPr.1> is the parameter of Unload Pressure band 1

<LPr.2> is the parameter of Load Pressure band 2

<uPr.2> is the parameter of Unload Pressure band 2

- Scroll Up or Down buttons (4-8) and press Enter button (7) to select parameter.
- The actual pressure used is shown. Scroll Up or Down buttons (4-8) to set pressure value and press Enter button (7) to confirm. The unit blinks and the new setting is saved.

3.18 Calling up/modifying the unit of temperature

The unit of temperature measurement can only be changed when the compressor is stopped.

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <ProG> and press Enter button (7) to enter the Programming menu.
- Scroll Up or Down buttons (4-8) to <diSp> for display settings.
- Press Enter button (7) to enter the submenu.
- Scroll Up or Down buttons (4-8) to <tEMP> and press Enter button (7).
- The actual unit used is shown. Possible settings are <°C > and <°F >.
- Scroll Up or Down buttons (4-8) to set the unit of temperature and press Enter button (7) to confirm. The unit blinks and is saved.

3.19 Calling up/modifying the unit of pressure

The unit of pressure measurement can only be changed when the compressor is stopped.

Starting from the Main screen:

- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <ProG> and press Enter button (7) to enter the Programming menu.
- Scroll Up or Down buttons (4-8) to <diSp> for display settings.
- Press Enter button (7) to enter the submenu.
- Scroll Up or Down buttons (4-8) to <PrES> and press Enter button (7).
- The actually used unit is shown. Possible settings are <bar>, <psi> and <MPa>.
- Scroll Up or Down buttons (4-8) to set the unit of pressure and press Enter button (7) to confirm. The unit blinks and is saved.

3.20 Calling up/modifying backlight time

The backlight will be activated after pressing any button and for the interval of time set in the parameter <bC.LG> (in sec).

Starting from the Main screen:


- Press Enter button (7) for 3 seconds to enter the Main menu.
- Select <ProG> and press Enter button (7) to enter the Programming menu.
- Scroll Up or Down buttons (4-8) to <diSp> for display settings.
- Press Enter button (7) to enter the submenu.
- Scroll Up or Down buttons (4-8) to <bC.LG> and press Enter button (7).
- The current backlight setting is shown. It is possible to set a value between 0s and 120s.
- Scroll Up or Down buttons (4-8) to set the time of backlight and press Enter button (7) to confirm. The unit blinks and is saved.

3.21 Activating automatic restart after voltage failure

Description

This function allows the compressor to restart automatically after voltage failure. The activation can only be done by your supplier. Please contact him for further details.

After any power failure, before restarting, the compressor will wait for a fixed time. When delay time is running, the display will show the related countdown value (in seconds) as below:




84725D

Example countdown delay time of automatic restart after power failure.

3.22 Keyboard lock

Keep both Up and Down buttons pressed for more than 3 seconds to lock or unlock the keyboard.

- The display will show the label <Loc> blinking for 3 seconds if the keyboard has been locked.
- The display will show the label <UnLo> blinking for 3 seconds if the keyboard has been unlocked.



Example Lock/unlock screen.

4 Installation

4.1 Installation proposal

Outdoor/altitude operation

If the compressor is installed outdoors or if the ambient temperature can be below 0°C (32°F), precautions must be taken. In this case, and also if operating at high altitude, consult Atlas Copco.

Moving/lifting




Transport by a pallet truck



For transport with a fork truck, use the openings in the frame.
Move the compressor gently.

Installation proposal



Installation proposal, G 15L, G 18 and G 22

Ref.	Action
1	<p>Install the compressor on a solid, level floor suitable for taking its weight. The recommended minimum distance between the top of the unit and the ceiling is 900 mm (35.1 in). The air receiver should not be bolted to the floor. For tank-mounted units, the minimum distance between the wall and the back of the compressor is 300 mm (19.5 in).</p>
2	<p>Position of the compressed air outlet valve. Close the valve. Connect the air net to the valve.</p>
3	<p>The pressure drop over the air delivery pipe can be calculated as follows: $\Delta p = (L \times 450 \times Q_c^{1.85}) / (d^5 \times P)$, with d = Inner diameter of the pipe in mm Δp = Pressure drop in bar (recommended maximum: 0.1 bar (1.5 psi)) L = Length of the pipe in m P = Absolute pressure at the compressor outlet in bar Q_c = Free air delivery of the compressor in l/s</p>

Ref.	Action
4	Ventilation: the inlet grids and ventilation fan should be installed in such a way that any recirculation of cooling air to the compressor or dryer is avoided. The air velocity to the grids must be limited to 5 m/s (200 in/s). The required ventilation capacity to limit the temperature of the compressor room can be calculated from the following formula: $Q_v = 0.92 N / \Delta T$ Q_v = Required ventilation capacity in m ³ /s N = Shaft input of compressor in kW ΔT = Temperature increase in the compressor room in °C
5	Position of the mains cable entry.
6	The drain pipes to the drain collector must not dip into the water of the drain collector.

4.2 Dimension drawings


The dimension drawing can be found in the technical documentation supplied with the unit.

Dimension drawing	Model
9828 0837 16	G 15L, G 18, G 22 Pack, floor-mounted
9828 0837 17	G 15L, G 18, G 22 Pack, tank-mounted
9828 0837 52	G 15L, G 18, G 22 Full-Feature, floor-mounted
9828 0837 53	G 15L, G 18, G 22 Full-Feature, tank-mounted

Text on drawings	Translation or explanation
Emergency stop switch	Emergency stop switch
Power supply	Power supply
Cooling air and compressor inlet	Cooling air and compressor inlet
Cooling air outlet of compressor and motor	Cooling air outlet of compressor and motor
Service panel	Service panel
Compressor controller	Compressor controller
Oil level indicator	Oil level indicator
Compressed air outlet (G1/2" Female)	Compressed air outlet
Forklift openings	Forklift openings
Valve rotation	Valve rotation
Center of gravity	Center of gravity
Cubicle door fully open	Cubicle door fully open
Anchorpoints in base	Anchorpoints in base
Air receiver safety valve	Air receiver safety valve
Vessel anchor points	Vessel anchor points
Air receiver manual drain (G3/8" Female)	Air receiver manual drain
Dryer dewpoint indicator	Dryer dewpoint indicator
Condensate drain integrated dryer	Condensate drain integrated dryer
Dryer inlet cooling air	Dryer inlet cooling air

Text on drawings	Translation or explanation
Dryer outlet cooling air	Dryer outlet cooling air

4.3 Electrical connections

	Always disconnect the power supply before working on the electrical circuit!
-----------------------------------------------------------------------------------	------------------------------------------------------------------------------

General instructions


Step	Action
1	Install an isolating (disconnecter) switch near the compressor.
2	Check the fuses and the setting of overload relay. See Settings for overload relay and fuses .
3	If fitted, check transformers for correct connection.
4	See Electric cable size for selection of power supply line cable. Connect the power supply cables to terminals L1, L2 and L3 (terminal block 1X0) and the neutral conductor (if applicable) to terminal (N). Connect the earth conductor to terminal PE/GND.

Specific voltage change instructions for G 15L – G 22 with 200 V / 230 V / 460 V cubicle

The standard voltage configuration for the compressor is mentioned on the data plate of the machine.

When the compressors leave the factory, the units are connected for 230 V / 3 phase.

To modify the wiring for an operating voltage of 200 V or 460 V, the main cubicle should be rewired as described below:




G 15L – G 22 200/230/460V 60Hz

Modifications to the compressor cubicle:

Step	Action
1	Adjust the motor overload (F21) setting.
2	Control transformer (T1) – Move the primary connection from 230V to the desired voltage.
3	Replace the control fuses (F1) 10.3 x 38mm with the ones provided (see further). Use 2A fuses for 460V or 5A for 200V On Full-Feature units, replace the power fuses (F7) with the CC type provided. Use 12A for 460V, and 25A for 200V.
4	Modify the motor terminal bridge configuration in the cubicle (1X1). See further for details.
5	Replace the voltage sticker by the appropriate voltage sticker provided.

Motor overload relay (F21) setting:

Rotate the adjustment screw (1) on the front of the relay to the required value.




Adjustment screw of the motor overload

Motor overload (F21) settings	15 kW	18 kW	22 kW
	20 hp	25 hp	30 hp
200 V	41.2	49.6	58.6
230 V (Standard factory setting)	36.6	44.2	51.7
460 V	18.3	22.1	25.9

Control transformer (T1):

Move the wire to the terminal marked with the desired voltage (200 V, 230 V or 460 V).



Transformer T1

Fuses F1 – F7:


The fuses are supplied with the compressor.

Fuses	Fuse rating (V)	200 V	230 V	460 V	Class
F1	600 V AC	5 A	5 A	2 A	UL class JDYX or JDYX2 10.3 x 38mm

(1): Fuse F7 only applicable to Full-Feature units . See also [Electrical system](#) for the service diagrams.

Motor terminal bridge configuration:

Factory standard connection is 230 V and can be changed to 200 V or 460 V.



Terminal bridges (1) can be removed using a pair of pliers.

Additional terminal bridges are provided with the compressor.


Voltage stickers:

Locate the yellow voltage labels provided with the compressor.

Replace the existing label with the appropriate voltage label (200 V, 230 V or 460 V).


Dryer transformer (T2):

Move the wire to the terminal marked with the desired voltage (200 V, 230 V or 460 V).



Transformer T2

4.4 Pictographs



Ref.	Description
1	Working pressure
2	Hour meter
3	Dew point temperature
4	Start
5	Stop
6	Warning: voltage
7	Lightly oil gasket of oil filter, screw filter on and tighten by hand
9	Warning: switch off voltage and depressurise compressor before carrying out maintenance work

5 Operating instructions


5.1 Initial start-up

Safety




The operator must apply all relevant [Safety precautions](#).


General preparation



Air outlet valve on air receiver



Condensate drain



Condensate drain valve on air receiver

Step	Action
1	Consult the installation instructions (see Installation).
2	Check that the electrical connections correspond to the local codes. The installation must be earthed and protected against short circuits by fuses in all phases. An isolating switch must be installed near the compressor.
3	Fit outlet valve (2), close it and connect the air net to the valve. Connect condensate drain valve (Dm) and automatic drain outlet (Da) to a drain collector. Close the valve. Connect condensate drain valve (4) of the air receiver to a drain collector. Close the valve.

Oil system




Oil level sight-glass

Step	Action
1	Check the oil level. Stop the unit and wait for the foam to disappear (normally about 3 minutes). The oil level should be visible on the sight glass (SG). Never measure the oil level on a unit that has been stopped for more than 10 minutes.


Start-up

Step	Action
1	Switch on the voltage. Press the start button for at least 3 seconds. If the motor rotation direction is correct, the compressor starts. If the rotation direction of the motor is incorrect, the compressor doesn't start and the controller display will show an alarm. Switch off the voltage, open the isolating (disconnecter) switch (IG) and reverse two phases of the supply cable. Switch on the voltage and restart the compressor. The shutdown message will disappear automatically when the shutdown condition has disappeared
2	Start and run the compressor for a few minutes. Check that the compressor is operating normally.


5.2 Starting



Air outlet valve on air receiver




Condensate drain valve on air receiver




Dew point temperature gauge


Starting the compressor



Position of oil sight glass and filler plug




Control panel

Step	Action
1	Before starting, check the oil level in accordance with step 5 of this table.
2	Switch on the voltage.
3	Open air outlet valve (2).
4	Push the start button (6) and the motor starts running. On compressors with a star-delta starter, the drive motor switches over from star to delta 4 seconds after starting.
	The maximum number of motor starts must be limited to 10 per hour. It is strongly recommended to operate the compressor with a load factor of more than 10% to avoid condensate in the oil.
5	Regularly check the oil level. 10 to 15 minutes after stopping, the oil should be visible through the sight glass (SG). If the oil level is too low, stop the compressor, depressurise the oil system by unscrewing oil filler plug (FC) one turn and wait a few minutes. Remove the plug and top up the oil, until the sight glass is 3/4 full. Do not overfill. Fit and tighten plug (FC).


Step	Action
6	In automatic operation, the regulator is automatically controlling the compressor, i.e. loading, unloading, stopping of the motors and restarting.
7	Regularly check the working pressure and the dew point (Full-Feature units).
8	Regularly check that condensate is drained (Da) during operation.

5.3 Stopping




80676F

Air outlet valve





85363D

Condensate drain valve on air receiver




84794D


Control panel

Step	Action
1	<p>Push the start/stop button (6) on the controller. The compressor will unload. When the unload time has elapsed, the compressor is stopped and the controller goes back to the main screen.</p> <p>To stop the compressor immediately in the event of an emergency, press button (S3). See section Control panel. After remedying the fault, unlock the button by rotating it.</p>
	<p>Only use emergency stop button in the event of an emergency. Avoid using the button for normal stopping of the compressor.</p>
2	<p>Close air outlet valve (2) and switch off the voltage to the compressor.</p>
3	<p>Open condensate drain valve (4) of the air receiver for a few seconds to drain any condensate and then close the valve.</p>
	<p>The air dryer and the air receiver remain under pressure. The integrated filter (if installed) remains pressurised. If maintenance or repair work is necessary, consult the Problem solving section for all relevant safety precautions.</p>

5.4 Taking out of operation



Air outlet valve



Condensate drain valve on air receiver



85367D

Oil filler plug


This procedure should be carried out at the end of the compressor's service life.

Step	Action
1	Stop the compressor and close the air outlet valve (2).
2	Switch off the voltage and disconnect the compressor from the mains.
3	Depressurize the compressor by opening plug (3) one turn. Open condensate drain valve (Dm). Open condensate drain valve (4) of the air receiver.
4	Shut off and depressurize the part of the air net which is connected to the outlet valve. Disconnect the compressor from the air net.
5	Drain the oil and condensate circuits.
6	Disconnect the compressor condensate outlet and valve from the condensate net.

6 Maintenance

6.1 Preventive maintenance schedule

Warning

	<p>Before carrying out any maintenance, repair work or adjustments, proceed as follows:</p> <ul style="list-style-type: none"> • Stop the compressor. • Switch off the voltage and open the isolating switch. • Close the air outlet valve and open the manual condensate drain valves. • Depressurize the compressor. <p>For detailed instructions, see the next sections. The operator must apply all relevant Safety precautions.</p>
-----------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Warranty-Product Liability

Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.

General

When servicing, replace all removed gaskets, O-rings and washers.

Intervals

Carry out maintenance at the interval which comes first. The local Atlas Copco Customer Center may overrule the maintenance schedule, especially the service intervals, depending on the environmental and working conditions of the compressor.

The "longer interval" checks must also include the "shorter interval" checks.

Preventive maintenance schedule

Period (1)	Running hours (1)	Action
Daily	--	Check the oil level. After stopping, drain the condensate from the air receiver by means of the manual drain valve (4), see section Stopping .
--	50	Check belt tension. Adjust if necessary.
Monthly	--	For Full-Feature versions: inspect the condenser of the dryer; clean if necessary. Press the test button on top of the electronic water drain (EWD). Open the manual drain valve(s) (Dm, Dm1) to clean the filter inside the EWD.
3-monthly	--	For compressors with PDX filter: check the service indicator; replace the filter if necessary.
"	500 (2)	Inspect the air filter. Clean if necessary.
"	1000	Check the tension and the condition of the belts. Adjust if necessary.
"	1000 (2)	Inspect the oil cooler; clean if necessary.


Period (1)	Running hours (1)	Action
“	“	For Full-Feature versions: inspect the condenser of the dryer; clean if necessary.
Yearly	4000	Replace the oil filter.
“	4000 (3)	If Roto-Inject Fluid Ndurance is used, change the oil.
“	4000 (2)	Replace the air filter.
“	4000 (2)	Replace the oil separator.
“	4000	Check and, if needed, replace the belts.
“	4000	On Full-Feature versions: clean the condenser of the dryer and apply the drain wear kit.
“	--	Have the safety valve tested.
“	“	Have the operation of sensors, electrical interlockings and components checked.
“	“	Have the temperature shut-down switch tested.
“	--	Inspect the air receiver. The air receiver must no longer be used and must be replaced if the wall thickness is less than the minimum value, specified in the technical documentation of the air receiver.
“	8000 (3)	If Roto Synthetic Fluid Xtend Duty is used, change the oil.
“	8000	Service the instrument block: Thermostatic and MPV kit.
“	8000	Check and clean the inlet valve. Use the unloader kit.
“	8000	Replace the belts.

(1): whichever comes first

(2): more frequently in a dusty environment

(3): The indicated oil exchange intervals are valid for standard operating conditions (see section [Reference conditions and limitations](#)) and nominal operating pressure (see section [Compressor data](#)). Exposure of the compressor to external pollutants or operation at high humidity combined with low duty cycles may require a shorter oil exchange interval. Contact Atlas Copco if in doubt.

Important

	<ul style="list-style-type: none"> • Always consult Atlas Copco if a service timer setting has to be changed. • For the change interval of oil and oil filter in extreme conditions, consult your Atlas Copco Customer Center. • Any leakage should be attended to immediately. Damaged hoses or flexible joints must be replaced.
-------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

6.2 Drive motor


General

Keep the outside of the electric motor clean for efficient cooling. If necessary, remove dust with a brush and/or compressed air jet.

Description

The motor bearings are greased for life.

6.3 Oil specifications

	Avoid mixing lubricants of different brands or types as they may not be compatible and the oil mix may have inferior properties. A label, indicating the type of oil filled ex factory, is stuck on the air receiver/oil tank.
-----------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

It is strongly advised to use the recommended lubricants. See section Preventive maintenance schedule for recommended oil change intervals.

For part numbers, consult the Spare Parts List.

Roto-Inject Fluid NDURANCE

Exchange interval for Roto-Inject Fluid Ndurance

Ambient temperature	Element outlet temperature	Exchange interval *	Maximum time interval *
up to 30°C (86°F)	up to 95°C (203°F)	4000	1 year
from 30°C (86°F) up to 35°C (95°F) (see note)	from 95°C (203°F) up to 100°C (212°F)	3000	1 year
from 35°C (95°F) up to 40°C (104°F) (see note)	from 100°C (212°F) up to 105°C (221°F)	2000	1 year
above 40°C (104°F)	above 105°C (221°F)	use Roto Synthetic Fluid XTEND DUTY	

Note: The presence of dust and/or high humidity may require a shorter exchange interval. Consult Atlas Copco.

Atlas Copco's Roto-Inject Fluid Ndurance is a premium mineral oil based 4000 hours lubricant, specially developed for use in single stage oil-injected screw compressors running in mild conditions. Its specific formulation keeps the compressor in excellent condition. Roto-Inject Fluid Ndurance can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 40 °C (104 °F). If the compressor is regularly operating in ambient temperatures between 40 °C and 46 °C (115 °F), it is recommended to use Roto Synthetic Fluid ULTRA or Roto Synthetic Fluid XTEND DUTY.

Roto Synthetic Fluid ULTRA

Exchange interval for Roto Synthetic Fluid Ultra

Ambient temperature	Element outlet temperature	Exchange interval *	Maximum time interval *
up to 35°C (95°F)	up to 100°C (212°F)	6000	2 years
from 35°C (95°F) up to 40°C (104°F) (see note)	from 100°C (212°F) up to 105°C (221°F)	4000	2 years
from 40°C (104°F) up to 45°C (113°F) (see note)	from 105°C (221°F) up to 110°C (230°F)	2000	2 years

Note: The presence of dust and/or high humidity may require a shorter exchange interval. Consult Atlas Copco.

Roto Synthetic Fluid ULTRA is a synthetic oil based 4000 hours lubricant, specially developed for use in single stage oil-injected screw compressors running in demanding conditions. Roto Synthetic Fluid ULTRA can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 45 °C (113 °F). For more extreme conditions or when longer oil life is required, it is recommended to use Roto Synthetic Fluid XTEND DUTY.

Roto Synthetic Fluid XTEND DUTY

Exchange interval for Roto Synthetic Xtend Duty

Ambient temperature	Element outlet temperature	Exchange interval *	Maximum time interval *
up to 35°C (95°F)	up to 100°C (212°F)	8000	2 years
from 35°C (95°F) up to 40°C (104°F) (see note)	from 100°C (212°F) up to 105°C (221°F)	6000	2 years
above 40°C (104°F)	above 105°C (221°F)	5000	2 years

Note: The presence of dust and/or high humidity may require a shorter exchange interval. Consult Atlas Copco.

Atlas Copco's Roto Synthetic Fluid XTEND DUTY is a high quality synthetic 8000 hours lubricant for oil injected screw compressors which keeps the compressor in excellent condition. Because of its excellent oxidation stability, Roto Synthetic Fluid XTEND DUTY can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 46 °C (115 °F). Roto Synthetic Fluid XTEND DUTY is the standard lubricant for oil injected screw compressors equipped with freeze protection or Energy Recovery.

Roto-Foodgrade Fluid

Exchange interval for Roto-Foodgrade Fluid

Ambient temperature	Element outlet temperature	Exchange interval *	Maximum time interval *
up to 35°C (95°F) (see note)	up to 100°C (212°F)	4000	1 year
from 35°C (95°F) up to 40°C (104°F) (see note)	from 100°C (212°F) up to 105°C (221°F)	3000	1 year
from 40°C (104°F) up to 45°C (113°F) (see note)	from 105°C (221°F) up to 110°C (230°F)	2000	1 year
above 45°C (113°F)	above 110°C (230°F)	use not recommended	

Note: The presence of dust and/or high humidity may require a shorter exchange interval. Consult Atlas Copco.

Special oil, delivered as an option.

Atlas Copco's Roto-Foodgrade Fluid is a unique high quality synthetic lubricant, specially created for oil injected screw compressors that provide air for the food industry. This lubricant keeps the compressor in excellent condition. Roto-Foodgrade Fluid can be used for compressors operating at ambient temperatures between 0 °C (32 °F) and 40 °C (104 °F).

Roto-Foodgrade Fluid has all required certification for use in food & beverage industry: like NSFH1, Kosher, Halal and Allergen Free approvals.


6.4 Oil, filter and separator change

Important



Never mix oils of different brands or types. A label, indicating the type of oil filled ex-factory, is attached on the air receiver/oil tank.
 Always drain the compressor oil at all drain points. Used oil left in the compressor can shorten the lifetime of the new oil.
 If the compressor is exposed to external pollutants, used at high temperatures (oil temperature above 90°C / 194°F) or used under severe conditions, it is advised to change the oil more frequently. Consult your supplier.


Location of oil filter and separator




85368D

Step	Action
1	Run the compressor until warm. Stop the compressor, close the air outlet valve and switch off the voltage. See Stopping .
2	Depressurize the air receiver by opening drain valve (8).
3	Depressurize the compressor by unscrewing filler plug (2) one turn to permit any pressure in the system to escape. Remove the plug after the system is depressurized.
4	Drain the oil by opening drain valve (6). Close the valve and refit the plug after draining. Deliver the drained oil to the local oil collection service.
5	Remove oil filter (7) and, if it needs to be replaced, remove the oil separator (1). Clean the seats on the manifold.
6	Oil the gaskets of the new filter and separator and screw them into place. Tighten firmly by hand.
7	Fill oil separator/tank (3) with oil until the level reaches the middle of sight-glass (4). Ensure no dirt gets into the system.
8	Refit and tighten filler plug (2).
9	Close drain valve (8) of the air receiver.
10	Run the compressor for a few minutes.
11	Stop the compressor and wait a few minutes to allow the oil to settle.
12	If the oil level is too low, depressurize the system by unscrewing filler plug (2) one turn to permit any pressure in the system to escape. Depressurize the air receiver by opening drain valve (8).
13	Add oil as necessary. The sight-glass should be 3/4 full. Retighten plug (2) and close drain valve (8) of the air receiver.

Checking the oil level



Step	Action
1	Run the compressor until warm. Stop the compressor, close the air outlet valve and switch off the voltage. See Stopping .
2	Depressurize the air receiver by opening drain valve (8).
3	Open the front panel.
4	Depressurize the compressor by unscrewing filler plug (2) one turn to permit any pressure in the system to escape. Remove the plug after the system is depressurized.
5	Wait 5 minutes for the foam in the oil collector to disappear.


Step	Action
6	Check the oil level through the sight-glass (4). If the oil level is lower than the minimum level, add oil until the maximum level is reached.
	Never mix oils of different brands or types. A label, indicating the type of oil filled ex-factory, is attached on the air receiver/oil tank. Before carrying out any operation on the machine, ensure that the electric power supply has been disconnected and that the machine has been depressurized. Run the compressor for at least 5 minutes before checking the oil level. Do not wait too long after the compressor is stopped and the foam is disappeared. The oil may migrate.
7	Refit and tighten filler plug (2).
8	Close drain valve (8) of the air receiver.
9	Run the compressor for a few minutes.
10	Close the front panel.

6.5 PDX/DDX filter change (option)



85367D

Oil filler plug



85363D

Drain valve, air receiver

Step	Action
1	Stop the compressor, close the air outlet valve, switch off the voltage and depressurise by unscrewing oil filler plug (3) one turn to permit any pressure in the system to escape. See section Stopping . On floor-mounted units, depressurise the filter by opening its drain valve. If the compressor is fitted onto an air receiver, depressurise the air receiver by opening condensate drain valve (4).
2	Unscrew the filter bowl. A whistling noise will warn you if the bowl is not fully depressurised. If this occurs, the bowl should be screwed back and the venting should be repeated.

Step	Action
3	Remove and discard the filter element.
4	Clean the bowl and replace its O-ring.
5	Fit the new filter element.
6	Refit the filter bowl.
7	Tighten oil filler plug (3).
8	Close condensate drain valve (4).

6.6 Storage after installation

If the compressor is stored without running from time to time, consult Atlas Copco as protective measures may be necessary.

6.7 Service kits

Service kits

For overhauling and for preventive maintenance, a wide range of service kits is available. Service kits comprise all parts required for servicing the component and offer the benefits of genuine Atlas Copco parts while keeping the maintenance budget low.

Also a full range of extensively tested lubricants, suitable for your specific needs is available to keep the compressor in excellent condition.

Consult the Spare Parts List for part numbers.

7 Adjustments and servicing procedures

7.1 Air filter

Changing the air filter




85369D

Air filter

Procedure:


Step	Action
1	Stop the compressor, close the air outlet valve and switch off the voltage. Open the isolating (disconnecter) switch (IG).
2	Remove the front panel and the top panel of the compressor housing.
3	Unscrew the filter cover (AF) and remove the filter element. Discard the air filter element.
4	Fit the new element and screw on the filter cover.
5	Refit the top and front panels.

7.2 Coolers



Step	Action
1	Keep the oil cooler (Co) clean to maintain the cooling efficiency. Also keep the cooler (Ca) clean to maintain the cooling efficiency.
2	Stop the compressor, close the air outlet valve and switch off the voltage. Remove any dirt from the oil cooler (Co) with a fibre brush. Open the isolating (disconnecter) switch (IG). Also remove any dirt from the air cooler (Ca). Never use a wire brush or metal objects. Then clean using an air jet.

7.3 Safety valve



Condensate drain valve



Oil filler plug

Testing

The valve can be tested on a separate compressed air line.

Before removing the safety valve, stop the compressor (see section [Stopping](#)), close the air outlet valve, switch off the voltage, open the isolating (disconnect) switch (IG), open drain valves (4) (tank-mounted units) and the manual drain valve (5) (if fitted - on floor-mounted units) and unscrew filler plug (3) one turn to permit any pressure in the system to escape.




If the valve does not open at the set pressure stamped on the valve, replace the valve. No adjustments are allowed. Never run the compressor without a safety valve.


7.4 Belt set exchange and tensioning



Read the warning in the [Preventive maintenance schedule](#) section.


Checking the belt tension

Step	Action
1	Stop the compressor, close the air outlet valve and switch off the voltage. Open the isolating (disconnecter) switch (IG).
2	Remove the front door and the internal panel.
3	<p>The force and deflection varies with the power of the unit, and with the total running hours of the belt. The values to be measured are indicated with a label (1) on the frame:</p>  <p style="text-align: center;">85371D</p>
4	Refit the bodywork panels.


	Tensioning of the belts must be performed with specific dedicated tooling.
-------------------------------------------------------------------------------------	----------------------------------------------------------------------------


Adjusting the tension of the drive belts

Step	Action
1	Stop the compressor, close the air outlet valve and switch off the voltage. Open the isolating (disconnecter) switch (IG).
2	Remove the front door, the internal panel, the top cover and the pulley protection.
3	Loosen the 4 bolts (2) by one turn.
4	Adjust the belt tension by turning tensioning nut (1).

Step	Action
5	<p>The force and deflection varies with the power of the unit, and with the total running hours of the belt.</p> <p>The values to be measured are indicated with a label (1) on the frame:</p>  <p style="text-align: center;">85371D</p>
6	Retighten bolts (2).
7	Refit the bodywork panels.

Replacing the drive belts



Step	Action
	The belts (3) must be replaced as a set, even if only one of the belts is worn. Only use genuine Atlas Copco belts.
1	Stop the compressor, close the air outlet valve and switch off the voltage. Open the isolating (disconnecter) switch (IG).
2	Remove the front door, the internal panel, the top cover, the pulley protection and the left side panel.
3	Loosen the 4 bolts (2) by one turn.
4	Release the belt tension by loosening tensioning nut (1).
5	Remove the fan duct (4). Remove the belts.
6	Install the new belts.
7	Tension belts (3) as described above.
8	Reassemble the fan duct (4), the pulley protection and the internal protection panel.
9	Reassemble left side and top panel cover.
10	Check the belt tension after 50 running hours.

7.5 Dryer maintenance instructions

Safety precautions

Refrigeration dryers of ID type contain refrigerant HFC.

When handling refrigerant, all applicable [safety precautions](#) must be observed. Please be specifically aware of the following points:

- Contact of refrigerant with the skin will cause freezing. Special gloves must be worn. If contacted with the skin, the skin should be rinsed with water. On no account may clothing be removed.
- Fluid refrigerant will also cause freezing of the eyes; always wear safety glasses.
- Refrigerant is harmful. Do not inhale refrigerant vapours. Check that the working area is adequately ventilated.

Be aware that certain components such as the refrigerant compressor and the discharge pipe can become quite hot (up to 110 °C - 230 °F). Therefore, wait until the dryer has cooled down before removing the panels.

Before starting any maintenance or repair work, switch off the voltage and close the air inlet and outlet valves.

Local legislation

Local legislation may stipulate that:

- Work on the refrigerant circuit of the cooling dryer or on any equipment which influences its function must be undertaken by an authorised control body.
- The installation should be checked once a year by an authorised control body.


General

For all references see section Introduction.


The following remarks should be kept in mind:

- Keep the dryer clean.
- Brush or blow off the finned surface of condenser monthly.
- Switch off the voltage and close the air outlet valve.
- Remove the panel where the condenser is situated (see the picture below).
- Clean the condenser fins with compressed air. Do not use water or solvents.
- Close the panel.
- Inspect and clean the electronic condensate drain monthly.
 - Functioning of the drains can be checked by pushing the TEST button of the drain.
 - Cleaning of the drain filter can be done by opening the manual drain valve during a few seconds.

8 Problem solving




Control panel



Air outlet valve



Oil filler plug



Condensate drain valve on air receiver

Attention

	<p>Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability. Apply all relevant Safety precautions during maintenance or repair.</p>
	<p>Before carrying out any maintenance or repair work on the compressor: push the stop button (6). Wait until the compressor has stopped and switch off the voltage. See the Stopping section. Open the isolating (disconnect) switch (IG) to prevent an accidental start. Close air outlet valve (2) and depressurize the compressor by opening the oil filler plug (3) one turn. Open manual condensate drain valves (4 and/or 5).</p>
	<p>The air outlet valve (2) can be locked during maintenance or repair as follows:</p> <ul style="list-style-type: none"> • Close the valve. • Remove the screw fixing the handle. • Remove the handle. • Fit the screw.

Faults and remedies

For all references given hereafter, see [Air flow diagram](#), [Initial start-up](#) or [Regulating system](#).

	Condition	Fault	Remedy
1	Compressor starts running, but does not load after a delay time	Solenoid valve (Y1) out of order	Replace valve
		Inlet valve (IV) stuck in closed position	Have valve checked
		Leak in control air pipes	Replace leaking pipe
		Minimum pressure valve (Vp) leaking (when net is depressurised)	Have valve checked
2	Compressor air output or pressure below normal	Air consumption exceeds air output of compressor	Check equipment connected
		Choked air inlet filter element (AF)	Replace filter element
		Solenoid valve (Y1) malfunctioning	Replace valve
		Leak in control air pipes	Replace leaking pipe
		Inlet valve (IV) does not fully open	Have valve checked
		Oil separator (OS) clogged	Replace separator element

	Condition	Fault	Remedy
		Safety valves leaking	Replace valves
3	Air outlet temperature above normal	Insufficient cooling air or cooling air temperature too high	Check for cooling air restriction or improve ventilation of compressor room. Avoid recirculation of cooling air. If installed, check capacity of compressor room fan
		Oil level too low	Check and correct as necessary
		Cooler clogged	Clean cooler
		Compressor element (E) out of order	Consult Atlas Copco

9 Technical data

9.1 Electric cable size

Attention




The voltage on the compressor terminals must not deviate more than 10% from the nominal voltage.
 It is however highly recommended to keep the voltage drop over the supply cables at nominal current below 5% of the nominal voltage.
 If cables are grouped together with other power cables, it may be necessary to use cables of a larger size than those calculated for the standard operating conditions. Use the original cable entry. See section [Dimension drawings](#).
 To preserve the protection degree of the electric cubicle and to protect its components from dust from the environment, it is mandatory to use a proper cable gland when connecting the supply cable to the compressor.
 Local regulations remain applicable if they are stricter than the values proposed below.

IEC versions

For IEC-designed control panels, the below suggested cable sections are calculated according to EN60364-5-52 (Electrical installations of buildings - selection and erection equipment - current-carrying capacities in wiring systems).

Standard conditions refer to:

Multi-core copper cables with 70°C PVC or 90 °C XLPE/EPR insulation in cable conduits or cable trunking systems (installation method B2) at 30°C ambient temperature and operating at nominal voltage. The cables may not be grouped with other power circuits or cables.



Worst case conditions refer to:

- Ambient temperature > 30 °C (86 °F).
- Cables in closed raceway, conduit or trunking system (installation method B2) at 46 °C ambient temperature.
- Cables not grouped with other cables.

CSA/UL versions

For UL designed machines, calculations of cable sections are done according to UL508A (Industrial control panels).

For CSA, calculations of cable sections are done according to CSA 22.2 (Canadian electrical code).

Standard conditions refer to:

Maximum 3 copper conductors in raceway or cable with 85-90°C (185-194 °F) insulation at ambient temperature 30 °C (86 °F), operating at nominal voltage; cables not grouped with other cables.

Worst case conditions refer to:

- Ambient temperature > 30 °C (86 °F).
- Maximum 3 copper conductors in raceway or cable with 85-90 °C (185-194 °F) insulation at 46 °C (115 °F) ambient temperature and operating at nominal voltage.
- Cables not grouped with other cables.
- If the local conditions are more severe then the described standard conditions, the cables for worst case conditions should be used.

Recommended cable size

Pack version – PVC 70 °C / XLPE-EPR 90 °C

		G 15L	G 18	G 22
Frequency (Hz)	Voltage (V)	Cable size	Cable size	Cable size
IEC				
50	230	25 mm ² / 16 mm ²	50 mm ² / 25 mm ²	70 mm ² / 35 mm ²
50	400	10 mm ² / 10 mm ²	16 mm ² / 10 mm ²	25 mm ² / 16 mm ²
60	230	25 mm ² / 16 mm ²	50 mm ² / 25 mm ²	70 mm ² / 35 mm ²
60	380	16 mm ² / 10 mm ²	25 mm ² / 10 mm ²	25 mm ² / 16 mm ²
60	460	16 mm ² / 6 mm ²	16 mm ² / 10 mm ²	25 mm ² / 10 mm ²
CSA/UL				
60	200	AWG4	AWG3	AWG1
60	230	AWG4	AWG3	AWG1
60	460	AWG8	AWG8	AWG8
60	575	AWG8	AWG8	AWG6

Full-Feature version – PVC 70 °C / XLPE-EPR 90 °C

		G 15L	G 18	G 22
Frequency (Hz)	Voltage (V)	Cable size	Cable size	Cable size
IEC				
50	230	50 mm ² / 25 mm ²	50 mm ² / 35 mm ²	70 mm ² / 35 mm ²
50	400 400+N	16 mm ² / 10 mm ²	16 mm ² / 10 mm ²	25 mm ² / 16 mm ²

		G 15L	G 18	G 22
Frequency (Hz)	Voltage (V)	Cable size	Cable size	Cable size
60	230	50 mm ² / 25 mm ²	50 mm ² / 35 mm ²	70 mm ² / 35 mm ²
60	380	16 mm ² / 10 mm ²	25 mm ² / 16 mm ²	35 mm ² / 16 mm ²
60	460	16 mm ² / 10 mm ²	25 mm ² / 10 mm ²	25 mm ² / 16 mm ²
CSA/UL				
60	200	AWG3	AWG1	AWG1/0
60	230	AWG3	AWG2	AWG1/0
60	460	AWG8	AWG6	AWG6
60	575	AWG8	AWG8	AWG6

9.2 Settings for overload relay and fuses

Fuse calculations

Fuse calculations for IEC are done according to 60364-4-43 electrical installations of buildings, part 4: protection for safety- section 43: protection against overcurrent. Fuse sizes are calculated in order to protect the cable against short circuit. Fuse type aM is recommended but gG/gL is also allowed.

For UL designed machines, calculations of fuses are done according to UL508A (Industrial control panels).

For CSA, calculations of fuses are done according to CSA 22.2 (Canadian electrical code).

Fuse size is the maximum fuse size in order to protect the motor against short circuit.

- For CSA: fuse HRC form II
- For UL: fuse class J or RK5

If the local conditions are more severe than the described standard conditions, the fuses for worst case conditions should be used.

Pack version

Frequency (Hz)	Voltage (V)	G 15L		G 18		G 22	
		Overload relay FM1 (A)	Fuses FU (aM/gG)	Overload relay FM1 (A)	Fuses FU (aM/gG)	Overload relay FM1 (A)	Fuses FU (aM/gG)
50	230	36.0	63A / 80A	43.5	80A / 100A	50.4	100A / 100A
50	400	20.6	40A / 40A	25.2	50A / 50A	29.0	63A / 63A
60	380	21.7	40A / 50A	25.9	50A / 63A	30.5	63A / 80A
60	460	18.3	40A / 40A	22.1	40A / 40A	25.9	50A / 50A

Frequency (Hz)	Voltage (V)	G 15L		G 18		G 22	
		Overload relay FM1 (A)	FU Main fuses (A) (class J or RK5) + Disc. Switch IG size $\geq 1,25 \times$ FLA, see conn. Diagram.	Overload relay FM1 (A)	FU Main fuses (A) (class J or RK5) + Disc. Switch IG size $\geq 1,25 \times$ FLA, see conn. Diagram.	Overload relay FM1 (A)	FU Main fuses (A) (class J or RK5) + Disc. Switch IG size $\geq 1,25 \times$ FLA, see conn. Diagram.
60	200	41.2	80	49.6	100	58.6	110
60	230	36.6	80	44.2	100	51.7	110
60	460	18.3	45	22.1	50	25.9	60
60	575	14.5	40	17.5	50	20.6	50

Full Feature version

Frequency (Hz)	Voltage (V)	G 15L		G 18		G 22	
		Overload relay FM1 (A)	Fuses FU (aM/gG)	Overload relay FM1 (A)	Fuses FU (aM/gG)	Overload relay FM1 (A)	Fuses FU (aM/gG)
IEC							
50	230	36.0	80A / 80A	43.5	100A / 100A	50.4	100A / 125A
50	400	20.6	50A / 50A	25.2	50A / 63A	29.0	63A / 80A
60	380	21.7	40A / 50A	25.9	50A / 63A	30.5	63A / 80A
60	460	18.3	40A / 40A	22.1	40A / 50A	25.9	50A / 63A
CSA/UL							
60	200	41.2	100	49.6	125	58.6	150
60	230	36.6	100	44.2	125	51.7	150
60	460	18.3	50	22.1	60	25.9	70
60	575	14.5	40	17.5	50	20.6	60

9.3 Reference conditions and limitations

Reference conditions

Air inlet pressure (absolute)	bar	1
Air inlet pressure (absolute)	psi	14.5
Air inlet temperature	°C	20
Air inlet temperature	°F	68
Relative humidity	%	0
Working pressure	bar(e)	See Compressor data
Working pressure	psi	See Compressor data

Limitations

Maximum working pressure	bar(e)	See Compressor data
Maximum working pressure	psig	See Compressor data
Minimum working pressure	bar(e)	4
Minimum working pressure	psig	58
Minimum ambient temperature	°C	0
Minimum ambient temperature	°F	32

9.4 Compressor data

G 15L

Compressor type	15k W	100 psi	125 psi	150 psi	175 psi	7.5 bar	10 bar	13 bar
Frequency	Hz	60	60	60	60	50	50	50
Maximum (unloading) pressure UL units	bar	7.4	9.1	10.8	12.6	7.50	10	13
Maximum (unloading) pressure UL units	psig	107	132	157	182	109	145	189
Nominal working pressure	bar	6.9	8.6	10.3	12.1	7.0	9.5	12.5
Nominal working pressure	psig	100	125	150	175	102	138	181
Set-point, thermostatic valve	°C	60	60	60	60	60	60	60
Set-point, thermostatic valve	°F	15.6	15.6	15.6	15.6	15.6	15.6	15.6

G 18

Compressor type	18k W	100 psi	125 psi	150 psi	175 psi	7.5 bar	10 bar	13 bar
Frequency	Hz	60	60	60	60	50	50	50
Maximum (unloading) pressure UL units	bar	7.4	9.1	10.8	12.6	7.50	10	13
Maximum (unloading) pressure UL units	psig	107	132	157	182	109	145	189
Nominal working pressure	bar	6.9	8.6	10.3	12.1	7.0	9.5	12.5

Compressor type	18k W	100 psi	125 psi	150 psi	175 psi	7.5 bar	10 bar	13 bar
Nominal working pressure	psig	100	125	150	175	102	138	181
Set-point, thermostatic valve	°C	60	60	60	60	60	60	60
Set-point, thermostatic valve	°F	15.6	15.6	15.6	15.6	15.6	15.6	15.6

G 22

Compressor type	22k W	100 psi	125 psi	150 psi	175 psi	7.5 bar	10 bar	13 bar
Frequency	Hz	60	60	60	60	50	50	50
Maximum (unloading) pressure UL units	bar	7.4	9.1	10.8	12.6	7.50	10	13
Maximum (unloading) pressure UL units	psig	107	132	157	182	109	145	189
Nominal working pressure	bar	6.9	8.6	10.3	12.1	7.0	9.5	12.5
Nominal working pressure	psig	100	125	150	175	102	138	181
Set-point, thermostatic valve	°C	60	60	60	60	60	60	60
Set-point, thermostatic valve	°F	15.6	15.6	15.6	15.6	15.6	15.6	15.6

10 Instructions for use

Oil separator vessel

1	The vessel can contain pressurized air. This can be potentially dangerous if the equipment is misused.
2	This vessel must only be used as a compressed air/oil separator tank and must be operated within the limits specified on the data plate.
3	No alterations must be made to this vessel by welding, drilling or other mechanical methods without the written permission of the manufacturer.
4	The pressure and temperature of this vessel must be clearly indicated.
5	The safety valve must correspond with pressure surges of 1.1 times the maximum allowable operating pressure. It should guarantee that the pressure will not permanently exceed the maximum allowable operating pressure of the vessel.
6	Use only oil as specified by the manufacturer.

Air receiver (on tank-mounted units)

1	Corrosion must be prevented: depending on the conditions of use, condensate may accumulate inside the tank and must be drained every day. This may be done manually by opening the drain valve, or by means of the automatic drain, if fitted to the tank. Nevertheless, a weekly check of correct functioning of the automatic valve is needed. This has to be done by opening the manual drain valve and checking for condensate. Verify that no rust obstructions affect the drain system.
2	Yearly service inspection of the air receiver is needed, as internal corrosion can reduce the steel wall thickness with the consequent risk of bursting. Local rules need to be respected, if applicable. The use of the air receiver is forbidden once the wall thickness reaches the minimum value as indicated in the service manual of the air receiver (part of the documentation delivered with the unit).
3	Lifetime of the air receiver mainly depends on the working environment. Installing the compressor in a dirty and corrosive environment is not allowed, as this can reduce the vessel lifetime dramatically.
4	Do not anchor the vessel or attached components directly to the ground or fixed structures. Fit the pressure vessel with vibration dampers to avoid possible fatigue failure caused by vibration of the vessel during use.
5	Use the vessel within the pressure and temperature limits stated on the nameplate and the testing report.
6	No alterations must be made to this vessel by welding, drilling or other mechanical methods.

11 Guidelines for inspection

Guidelines

On the Declaration of Conformity / Declaration by the Manufacturer, the harmonised and/or other standards that have been used for the design are shown and/or referred to.

The Declaration of Conformity / Declaration by the Manufacturer is part of the documentation that is supplied with this compressor.

Local legal requirements and/or use outside the limits and/or conditions as specified by the manufacturer may require other inspection periods as mentioned below.

COMMITTED TO SUSTAINABLE PRODUCTIVITY

We stand by our responsibilities towards our customers, towards the environment and the people around us. We make performance stand the test of time. This is what we call — Sustainable Productivity.

www.atlascopco.com

